

RBFK - RETROFIT BATH FAN KITS

READ AND SAVE THESE INSTRUCTIONS FOR FUTURE REFERENCE

FAN INSTALLATION

1. Disconnect power supply to existing fan unit.
2. Remove grille.
3. Remove fan, motor assembly and mounting plate.
4. Dismantle and discard existing fan and motor assembly.
5. Retain mounting plate if it is required to re-install grille.
6. Install new AXC fan according to installation guide (enclosed), using new mounting hardware (supplied).
7. Utilize new flexible duct and reducers (supplied), connect AXC fan to existing duct.
(Note: replacing rigid duct with flexible duct may result in quieter operation).
8. Connect electrical wire (supplied) to AXC fan.
9. Connect electrical wire to power supply line in existing fan unit using wire nuts (supplied).
10. Re-install existing mounting plate and grille.
11. Reconnect power supply.

KIT INCLUDES



Mounting Brackets



*Wire Cable
Restraint*



*AXC
In-line Duct Fan*



*Mounting
Screws*



12' of No. 14 AWG Wire



*4"-3" Duct
Reducers (two)*



Wire Nuts



*12.5' of 4" Flexible
Insulated Duct*