

Product Information

Applicable product:	
G90 Slidebar kit	K-98361

Installation Notes

Install this product according to the installation guide.

Mount the slidebar to stud framing or install backing support.

For tile or other solid finish surfaces: Predrill mounting holes through surface material only; do not drill into the stud.

For drywall surface: No predrill is required.

NOTE: The mounting brackets can be adjusted to align with existing holes for retrofit installations.

