



Copper Basin Installation Instructions

Because Belle Forêt copper basins are handmade, overall and installation dimensions can vary in size from specifications, and from basin to basin. It is strongly recommended that the actual basin to be installed be used as the cut-out dimensions.

OVERCOUNTER INSTALLATION:

1. Place basin rim on countertop and lightly trace outer rim.
2. Draw a parallel line ½" inside the traced-rim line. This line is your cutout. Cut countertop along the inner line. (Adjustments may be necessary for lavatory overflows.)
3. Test fit basin and modify cutout as necessary.
4. Secure with silicone or other appropriate sealers.

UNDERCOUNTER INSTALLATION:

1. Place basin rim on countertop and lightly trace outer rim.
2. Cut countertop to conform to inside dimensions of basin, or as desired by customer.
3. Test fit basin and modify cutout as necessary.
4. Secure with optional mounting brackets (order separately), silicone or other appropriate sealers.