

Operation and Maintenance Manual

AirTube Junior/AirTube/AirTube Supreme Series



Congratulations!

You are moments away from fresher, cleaner indoor air. Your new AllerAir unit will combat many of the chemicals, gases, odors and particles responsible for poor indoor air quality, and in turn, health concerns such as allergies, asthma, sick building syndrome and multiple chemical sensitivity. As with any air cleaner, proper maintenance of your unit is a vital part of keeping it operating at peak efficiency.

Operation:

Your unit is shipped fully assembled and ready for use. Plug into 120V-15amp outlet. For best results situate your unit close to your sitting, sleeping or work area.

Note:

As original packaging is required for warranty returns, new AllerAir owners are advised to keep boxes and shipping materials.

Model No. _____

Serial No. _____

WARNING!

BEFORE REMOVING THE TOP OR BOTTOM OF THE UNIT FOR ANY REASON, ALWAYS UNPLUG THE CORD FROM THE POWER SUPPLY.

AIR TUBE & AIR TUBE SUPREME MAINTENANCE**The HEPA Filter**

- Should be changed after approximately 24 months of use in an average home environment.
- A reduced level of airflow is a sign that it may be time to replace this filter.

The Carbon Filter

- Should be changed after approximately 12 months of use in an average home environment.
- A noticeable decrease in air quality could also be a sign that it may be time to replace this filter.

The Pre-Filter

- Replace or vacuum from the outside of the unit every 2-3 months.

AIR TUBE JUNIOR MAINTENANCE:**The Micro-HEPA Filter**

- Should be changed after approximately 12 months of use in an average home environment.
- A reduced level of airflow is a sign that it may be time to replace this filter.

The Carbon Filter

- Should be changed after approximately 9-12 months of use in an average home environment.
- A noticeable decrease in air quality could also be a sign that it may be time to replace this filter.

REPLACEMENT PARTS ORDER REFERENCE NUMBERS*

To order replacement parts, call AllerAir toll-free at 1-888-852-8247 during regular business hours (EST), or send an e-mail to info@allerair.com

Models	AirTube Jr.	AirTube	AirTube Supreme
Carbon (Exec Models)	9" A2FCW301	9" A3FCW302	12" A3FCB401
Carbon (Vocarb Models)	9" A2FCW302	9" A3FCW303	12" A3FCB403
Micro-HEPA Wrap	A2FMR002 9x21	A3FH0410 HEPA	A3FH0420 HEPA
PRE-FILTER	–	A3FMP009	A3FMP012
Motor	A2EL0040	A2EL0040	A2EL0040
Switch	CMEL0046	CMEL0046	CMEL0046
Cord	A3EL0046	A3EL0046	A3EL0046
Handle	A4HD8414	A4HD8414	A4HD8414

*Please use the above part numbers when ordering your replacement parts.

REPLACING FILTER ASSEMBLY (AirTube & AirTube Supreme)

**STEP 1**

Turn power off and unplug receptacle.

**STEP 2**

Gently lay unit upside down. With a screw driver, remove all 4 screws.


**STEP 3**

Remove lid by pulling slightly on cover.

**STEP 4**


First remove HEPA filter by placing your hand on the inner side of the filter.

Pull gently until completely removed.

**STEP 5**

Now remove carbon filter by placing hands on the inner side of the filter.

Pull gently until completely removed.

**STEP 6**

A - To replace pre-filter, gently remove pre-filter from carbon canister and replace with new one.

B - To replace anti-microbial filter, peel off filter liner.

**STEP 7**

Replace all filters with new ones then reassemble by inserting the carbon filter first then the HEPA.


**STEP 8**

Place lid back to its proper position by aligning screw holes.

**STEP 9**


With a screw driver, place 4 screws back into their positions.

REPLACING FILTER ASSEMBLY (AirTube Junior)




STEP 1

Turn power off and unplug receptacle.



STEP 2

Gently lay unit upside down. With a screw driver, remove all 4 screws.




STEP 4

Remove carbon filter by placing hands on the inner side of the filter. Pull gently until completely removed.

STEP 3

Remove lid by pulling slightly on cover.



STEP 5

To replace the micro-HEPA filter, gently remove the filter from carbon canister and replace with a new one.



STEP 6

Replace all filters with new ones then reassemble by inserting the carbon filter.



STEP 7

Place lid back to its proper position by aligning screw holes.

STEP 8

With a screwdriver, replace 4 screws.

TEN YEAR LIMITED WARRANTY

Your AllerAir unit comes with a 10-year limited warranty excluding expendable parts such as pre-filters and filters. This warranty provides for the repair of any defective components and labor for 5 years from the date of delivery. An additional 5-year warranty is provided on parts. This product is not covered against damage resulting from misuse. This warranty is provided to the original purchaser and may not be transferred. A return authorization number is required for warranty repairs. Please contact AllerAir at 1-888-852-8247 for more information.