

Installation Instructions No. 117 & 118 Garbage Disposer Flange & Stopper



The Brasstech No. 117 or 118 Garbage Disposer Flange and Stopper fit most garbage disposers. The basic manufactures of disposers are In-Sink-Erator, General Electric, Waste King, Whiterock and Whirlaway. Some of these manufacturers also make disposers for other manufacturers and distributors who sell them under their own name brand. If your existing garbage disposer flange (the part that sits in the sink bottom and attaches to the disposer motor) looks like any of the three cross sections below; the Brasstech No. 117 or 118 will fit. If you have the In-Sink-Erator type cross section, place the rubber ring with the sharp point (one of the two rings supplied) in the bottom groove of the flange as shown in Figure 1. If you have one of the other cross sections (Whirlaway, General Electric, Waste King or Whiterock) place the other rubber ring in either the top or bottom groove as shown in Figure 2 & 3. When the correct rubber ring has been installed, simply push the flange into the existing flange, making sure it seats firmly. If you wish to remove the No. 117 or 118 flange once it is installed, simply pull up on it. NO sealant is required to hold it in place. Once the No. 117 or 118 flange is in place, push the stopper into it if desired.

