


# INSTALLATION AND WIRING DIAGRAM

## HIGH-LINE

### HIGH-LINE RAINBOW I

ART. NO.	150 721ch	chrome, orange glass	150 724ch	chrome, turquoise glass
	150 721mc	matte chrome, orange glass	150 724mc	matte chrome, turquoise glass
	150 722ch	chrome, smoky glass	150 913ch	chrome, rainbow glass
	150 722mc	matte chrome, smoky glass	150 913mc	matte chrome, rainbow glass
	150 723ch	chrome, red glass	150 918ch	chrome, sunrise glass
	150 723mc	matte chrome, red glass	150 918mc	matte chrome, sunrise glassvvv



## IMPORTANT SAFETY INSTRUCTIONS



1. Read all instructions!
2. Turn off power prior to any work on the systems.
3. Warranty is void in case of unauthorized modifications and/ or improper use.

## READ ALL OF THESE INSTALLATION INSTRUCTIONS BEFORE INSTALLING THE FIXTURE

### Contents of Delivery:

HIGH-LINE RAINBOW I - qty. (1)

#### Note

It is recommended to use the fixture as a down light only.

#### Step 1

- To connect High-Line Rainbow to cable, unscrew the two screws (A) at the ends of the fixture.

- When placed onto cable system, make sure screws have a clean connection to the cable.

