

# Microwaves

FFCE1638L W/B



## Countertop

### Product Dimensions

Height	12-7/8"
Width	21-3/4"
Depth	18-1/2"

### More Easy-To-Use Features

#### Ready-Select™ Controls

Easily select options with the touch of a button.

#### Auto One-Touch Options

Our microwaves feature easy-to-use one-touch buttons so you can cook beverages, baked potatoes, popcorn, fresh veggies or even add thirty seconds with the touch of a button.

#### Effortless™ Defrost

Makes it easy to defrost almost anything, quickly and evenly.

#### Effortless™ Reheat

Reheat almost anything at the touch of a button.

#### Multi-Stage Cooking

Our Multi-Stage Cooking option allows you to program power levels and cooking times in advance, so you can program it to defrost, cook and keep a meal warm all at once.

#### 10 Cooking Power Levels

Provides the versatility needed to prepare everything from frozen pizza to pot roast quickly and easily.

#### Control Lock Option

#### Electronic Clock/Timer

Helps you keep track of cook times.

#### Interior Light

Illuminates the contents of the microwave for increased visibility.

#### Large Glass Turntable

Even large items fit on our large glass turntable.

#### Available in:



White  
(W)

Black  
(B)

## Signature Features

### Sensor One-Touch Options

Microwave automatically adjusts power levels and cooking times to cook a variety of items, effortlessly.

### Melt & Soften

Use the microwave to quickly melt or soften butter or cheeses for your recipes.


### Keep Warm Setting

Keep food warm until everything—and everyone—is ready.

### Easy-Set™ Start

Quickly start cooking—one to six minutes—with just one touch.

Features	
Control/ Timing System	Ready-Select™
Exterior Door Finish	Color-Coordinated
Handle Design	Push Button
Microwave Features	
Microwave Capacity (Cu.Ft.)	1.6
Watts (IEC-705 Test Procedure)	1,100
Interior Light	Yes
Interior Color	White
Turntable Diameter	14-1/4"
Turntable On/Off	
Control Lock	Yes
Clock	Yes
Touch Pad Buttons	23
Power Levels	10
Accessory Metal Rack	
Microwave Control Options	
Easy-Set™ Start	Yes
Popcorn Button	Yes
Chicken Nugget Button	
Baked Potato Button	Yes
Sensor Reheat Button	Yes
Snack Button	
Beverage	Yes
Melt & Soften Options	4/ 4
Auto Reheat Options	
Snack Menu Options	
Auto Cook Options	
Auto Defrost Options	Yes
Keep Warm	Yes
Add-30-Seconds	Yes
Sensor Cooking Options	7
Vegetable Cook Sensor	Yes
Delay Start	
User Preferences	
Power Ratings	
Frequency (Mhz)	2,450
Watts @ 120 Volts	1,550
Amps @ 120 Volts	15
Specifications	
Oven Interior Height	10-5/16"
Oven Interior Width	17-1/4"
Oven Interior Depth	15-3/8"
Power Supply Connection Location	Rear
Voltage Rating	120V / 60Hz / 15A
Minimum Circuit Required (Amps)	15
Shipping Weight (Approx.)	47



NOTE: For planning purposes only. Always consult local and national electric codes. Refer to Product Installation Guide for detailed installation instructions on the web at [frigidaire.com](http://frigidaire.com).



Product Dimensions <sup>1</sup>	
A - Height	12-7/8"
B - Width	21-3/4"
C - Depth	18-1/2"

<sup>1</sup>A minimum clearance of 3 inches is required between microwave oven and adjacent walls. Leave a minimum clearance of 12 inches above microwave oven.

Accessories information available on the web at [frigidaire.com](http://frigidaire.com)

FRIGIDAIRE

USA • 10200 David Taylor Drive • Charlotte, NC 28262 • 1-800-FRIGIDAIRE • [frigidaire.com](http://frigidaire.com)  
 CANADA • 5855 Terry Fox Way • Mississauga, ON L5V 3E4 • 1-800-265-8352 • [frigidaire.ca](http://frigidaire.ca)

FFCE1638L W/B 08/10

© 2010 Electrolux Home Products, Inc.

Specifications subject to change.  
 Printed in the U.S.A.