



Hardware

(Drawn to Scale)





Fan Parts

(Not Drawn to Scale)



PARTS GUIDE

Hunter



Using this Parts Guide, make sure all parts are included in the box. If parts are missing, DO NOT RETURN


THIS ITEM TO THE STORE, call 888-830-1326 for assistance.

THIS PARTS GUIDE IS FOR REFERENCE ONLY. REFER TO THE INSTALLATION MANUAL FOR FULL ASSEMBLY INSTRUCTIONS.

Parts List	Model #	21808	21809	21810
	Asm. Dwg. #	G1264-01	G1264-02	G1264-03
	Finish	White	Brushed Nickel	New Bronze
Item Name	Qty	Part #	Part #	Part #
* Hanging System Kit	1	99667-03	99667-09	99667-30
Ceiling Plate				
Canopy				
Canopy Trim Ring				
Hanger Ball / Downrod Assembly				
Setscrew				
Low Profile Washer				
Canopy Screw				
Wood Screw				
Flat Washer				
Mounting Isolator				
Screw, Low Profile				
Switch Housing Assembly	1	G1202-03	G1202-09	G1202-30
Blade Set	1	G0677-61	G0677-62	G0677-62
Screw, Blade Iron Armature	11	63755-05	63755-05	63755-05
Blade Iron Set	1	G0989-05	G0989-05	G0989-05
Light Kit Assembly	1	98378-01	98378-01	98378-01
Hardware Kit	1	G1264-00-860	G1264-00-861	G1264-00-862
Wire Connector				
Screw, Switch Housing Assembly				
Pull Chain Pendant	1	G0090-01	G0090-01	G0090-01
Pull Chain Pendant	1	G0091-01	G0091-01	G0091-01
Pull Chain	1	63756-18	63756-18	63756-18
Pull Chain	2	63756-58	63756-58	63756-58
Bottom Cap	1	65932-01	65932-01	65932-01
Finial	1	74758-01	74758-01	74758-01
Globe/Shade	1	G1342-01	G1342-02	G1342-03
Dummy Terminal, Male	1	08198-01	08198-01	08198-01
Dummy Terminal, Female	1	08200-01	08200-01	08200-01
Cap, Switch Housing	1	73853-01	73853-01	73853-01
Plug Button	1	73854-01	73854-01	73854-01
Light bulb / Bulb	2	77646-08	77646-08	77646-08
Balancing Kit	1	65666-01	65666-01	65666-01


Materiales

(no dibujados a escala)



Piezas del ventilador

(no dibujadas a escala)




GUÍA DE PIEZAS

Hunter

ALTO

Consulte esta Guía de partes para asegurarse de que todas las partes estén incluidas en la caja.



Si falta alguna parte, **NO DEVUELVA ESTE PRODUCTO A LA TIENDA. Solicite ayuda al 888-830-1326. ESTA GUÍA DE PARTES SOLAMENTE ES REFERENCIAL. CONSULTE LAS INSTRUCCIONES COMPLETAS DE ENSAMBLAJE EN EL MANUAL DE INSTALACIÓN**

Lista de piezas

Nombre del ítem	No. del modelo			
	21808	21809	21810	
	No. del dibujo de ensamblaje			
	G1264-01	G1264-02	G1264-03	
	Acabado			
	Blanco	Níquel Cepillado	Bronce Nuevo	
Nombre del ítem	Cantidad	No. de la pieza	No. de la pieza	No. de la pieza
Kit del sistema de suspensión	1	99667-03	99667-09	99667-30
Placa de techo				
Campana				
Anillo de la moldura de campana				
Bola de suspensión / Conjunto de varilla				
Tornillo prisionero				
Roseta de perfil bajo				
Tornillo, de campana				
Tornillo, de madera				
Arandela, plana				
Aislador de montaje				
Tornillo, de roseta de perfil bajo				
Conjunto del interruptor	1	G1202-03	G1202-09	G1202-30
Juego de paletas	1	G0677-61	G0677-62	G0677-62
Tornillo, de armadura de soporte de paleta	11	63755-05	63755-05	63755-05
Juego de soporte de paletas	1	G0989-05	G0989-05	G0989-05
Conjunto del kit de luz	1	98378-01	98378-01	98378-01
Kit de materiales	1	G1264-00-860	G1264-00-861	G1264-00-862
Empalme plástico				
Tornillo, del conjunto de la caja del interruptor				
Pendiente del tirador de cadena	1	G0090-01	G0090-01	G0090-01
Pendiente del tirador de cadena	1	G0091-01	G0091-01	G0091-01
Tirador de cadena	1	63756-18	63756-18	63756-18
Tirador de cadena	2	63756-58	63756-58	63756-58
Tope inferior	1	65932-01	65932-01	65932-01
Cubierta ornamental	1	74758-01	74758-01	74758-01
Globo / Pantalla	1	G1342-01	G1342-02	G1342-03
Terminal simulado, macho	1	08198-01	08198-01	08198-01
Terminal simulado, hembra	1	08200-01	08200-01	08200-01
Tapa, Caja del interruptor	1	73853-01	73853-01	73853-01
Botón taponador	1	73854-01	73854-01	73854-01
Bombilla	2	77646-08	77646-08	77646-08
Kit de equilibrado	1	65666-01	65666-01	65666-01