

## MODEL#70034

### ASSEMBLY INSTRUCTIONS

**\*\*CAUTION: DO NOT PLUG THE LAMP INTO ELECTRICAL  
OUTLET BEFORE ASSEMBLY IS COMPLETED\*\***

1. CAREFULLY LAY OUT ALL LAMP PARTS FROM THE BOX  
AND PLACE THEM ON FLAT SURFACE.
2. ATTACH SOCKET ASSEMBLY TO BODY
3. INSERT THE HARP INTO CRADLE.
4. PLACE SHADE ON TOP OF THE HARP AND TIGHTEN WITH FINIAL.

*TO CLEAN, USE SOFT CLOTH ONLY. DO NOT USE ANY  
CHEMICAL OR ABRASIVE CLEANERS.*

### IMPORTANT SAFETY INSTRUCTIONS

THIS PORTABLE LAMP HAS A POLARIZED PLUG ( ONE BLADE IS WIDER  
THAN THE OTHER) AS A SAFETY FEATURE TO REDUCE THE RISK OF  
ELECTRIC SHOCK. THIS PLUG WILL FIT IN A POLARIZED OUTLET ONLY  
ONE WAY. IF THE PLUG DOES NOT FIT FULLY IN THE OUTLET, REVERSE  
THE PLUG. IF IT STILL DOES NOT FIT, CONTACT A QUALIFIED  
ELECTRICIAN. NEVER USE WITH AN EXTENSION CORD UNLESS  
PLUG CAN BE FULLY INSERTED. DO NOT ALTER THE PLUG.

