

INSTALLATION INSTRUCTION

Item#8619 (Rev. 05/10/2012)

READ AND SAVE THESE INSTRUCTIONS

WARNING! SHUT POWER OFF AT FUSE OR CIRCUIT BREAKER
AVERTISSEMENT! COUPER LE COURANT AU NIVEAU DES FUSIBLES OU DU DISJONCTEUR.

MOUNTING THE FIXTURE (Fig.1)

1. Carefully unpack your new fixture and lay out all the parts on a clear area. Take care not to lose any parts necessary for installation.
2. Shut off power at the fuse box or circuit breaker. Remove the old fixture from ceiling, including the mounting hardware.
3. Thread the two mounting screws (C) 1/4" into the pre-drilled holes in the crossbar (A) spaced the same distance apart as the holes in the ceiling pan (D).
4. Attach the crossbar (A) to the outlet box using the two screws (B). The side of the crossbar marked "GND" must face out.

CONNECTING THE WIRES (Fig. 2)

5. While holding the ceiling pan (D) toward the ceiling, connect the electrical wires as shown in (Fig.2), making sure that all wire connectors are secured. If your outlet has a ground wire (green or bare copper), connect the fixture ground wire to it. Otherwise, connect the fixture ground wire directly to the crossbar using the green screw provided.
6. After wires are connected, tuck them carefully into the outlet box. Place the ceiling pan (D) over the mounting screw (C) and tighten with a screwdriver.
7. Install the light bulbs in accordance with the fixture's specifications. **(DO NOT EXCEED THE MAXIMUM WATTAGE RATING!!) (NE PAS DEPASSER LA PUISSANCE NOMINALE MAXIMALE!).**
8. Thread the nipple (E) into the ceiling pan (D). Place the glass shade (F) over the nipple and secure with bottom cap (G) and finial (H).

Your installation is now complete. Return power to the junction box and test the fixture.

Note: Illustration (Fig. 1) on this manual is for installation purposes only. It may or may not be identical to the fixture purchased.

