


Uttermost

Assembly Instruction ITEM#23003


UNPACK CARTON ON A SOFT.SMOOTH SURFACE-INVENTORY ALL PARTS.

Component List:


- A.Chair..... 1pc.
- B.Front Leg..... 2pcs.
- C.Back Leg..... 2pcs.
- D.Plastic Washer.... 4pcs.



Step 1. Put the **Chair (A)** on a soft, clean place as shown. Unzip the compartment located on the bottom of **Chair (A)**. Remove the **Front Legs (B)**, **Back Legs (C)** and **Plastic Washer (D)** packed inside. Close zipper.



Step 2. Turn the **Front Legs (B)** and **Back Legs (C)** along with **Plastic Washer (D)** to the bottom of arms as shown.



Step 3. Turn **Chair (A)** upright.

Assembly is complete now.
Thank you for your purchase.

