


**KitchenAid®**

**30" ELECTRIC SLIDE-IN SELF-CLEAN CONVECTION RANGE**

**MODELS:**

KSEB900EWHO (White)  
KSEB900EBL0 (Black)  
KSEB900ESS0 (Stainless)


# COOKTOP PARTS



# COOKTOP PARTS

| <u>Illus. No.</u> | <u>Part No.</u> | <u>Description</u>               | <u>Illus. No.</u> | <u>Part No.</u> | <u>Description</u>                     | <u>Illus. No.</u> | <u>Part No.</u> | <u>Description</u>                                   |
|-------------------|-----------------|----------------------------------|-------------------|-----------------|--|-------------------|-----------------|--|
| 1                 |                 | Literature Parts                 | 13                | W10289169       | Support, Cooktop (Right)               | 24                | 3196068         | Lens, Indicator                                      |
|                   | W10665255       | Installation Instructions        |                   | W10289170       | Support, Cooktop (Left)                | 25                | W10555923       | Bracket, User Interface                              |
|                   | W10722059       | Use and Care Guide               | 14                | 3196173         | Screw                                  | 26                | 7101P485-60     | Screw, Anti-Tip Kit                                  |
|                   | W10665227       | Sheet, Tech                      | 15                |                 | Endcap                                 | 27                | W10606241       | Bracket, Anti-Tip                                    |
|                   | 9762761         | Tips, Safe Cooking (English)     |                   | W10555935       | White (Left)                           | 28                | W10664705       | Bumper   |
|                   | W10065852       | Tips, Safe Cooking (French)      |                   | W10555936       | Black (Left)                           | 29                | W10603094       | Assembly, Display                                    |
|                   | W10400064       | Guide, Quick Start (English)     |                   | W10555938       | White (Right)                          | 30                | 7201P077-60     | Gasket, Infinite Switch                              |
|                   | W10400065       | Guide, Quick Start (French)      | 16                |                 | Console, Panel                         | 31                |                 | Console, Lower Panel                                 |
|                   | W10665238       | Wiring Diagram                   |                   | W10697318       | White                                  |                   | W10555933       | White  |
| 2                 | W10225448       | Spring, Element                  |                   | W10697317       | Black                                  |                   | W10555932       | Black  |
| 3                 | 3196178         | Screw                            |                   | W10697319       | Stainless                              |                   | W10555934       | Stainless  |
| 4                 |                 | Cooktop                          | 17                | W10578768       | Switch, Infinite (Single) (Right Rear) | 32                |                 | Bezel  |
|                   | W10536294       | White                            |                   |                 |  |                   | W10663809       | Stainless  |
|                   | W10536295       | Black                            | 18                | 8523265         | Light, Indicator (125V)                | 33                | W10558372       | Bracket, Control                                     |
|                   | W10536296       | Stainless                        | 19                |                 | Knob                                   | 34                | W10437097       | Switch, Infinite Triple (Left Front)                 |
| 5                 | W10187839       | Element (3000W) (Left Front)     |                   | W10579762       | Stainless (Right Rear)                 | 35                | W10437094       | Switch, Infinite (Hyper) (Right Front and Left Rear) |
| 6                 | 8273994         | Element (1200W) (Right Rear)     |                   | W10579763       | Stainless (Left Rear)                  | 36                | W10598048       | Bracket, Console (Center)                            |
| 7                 | W10251108       | Element (3200W) (Right Front)    |                   | W10579764       | Stainless (Right Front)                |                   |                 | FOLLOWING PARTS NOT ILLUSTRATED                      |
| 8                 | W10342780       | Element (1300W) (Left Rear)      |                   | W10579765       | Stainless (Left Front)                 |                   | W10580306       | Harness, Main  |
| 9                 | W10388247       | Element, Warm Zone (Center Rear) | 20                | 3400882         | Screw                                  |                   | W10575120       | Harness, Keypad                                      |
| 10                | W10613286       | Bracket, Radiant                 | 21                | W10453976       | Control, MRC2                          |                   | W10598170       | Harness, Display                                     |
| 11                | W10536275       | Pan, Radiant                     | 22                | W10645947       | Grommet                                |                   | W10580303       | Harness, Console                                     |
| 12                | W10162253       | Brace, Corner (Left)             | 23                |                 | Vent, Trim Top                         |                   | W10664316       | Clip, Harness  |
|                   | W10162252       | Brace, Corner (Right)            |                   | W10636527       | White                                  |                   | W10580316       | Harness, Bake Drawer                                 |
|                   |                 |                                  |                   | W10636528       | Black                                  |                   | W10580249       | Harness, Cooktop                                     |
|                   |                 |                                  |                   | W10636529       | Stainless                              |                   |                 |  |

# CHASSIS PARTS




# CHASSIS PARTS

| <u>Illus.</u><br><u>No.</u> | <u>Part No.</u> | <u>Description</u>          |
|-----------------------------|-----------------|-----------------------------|
| 1                           | W10289077       | Receiver, Hinge             |
| 2                           | W10362924       | Screw                       |
| 3                           |                 | Panel, Side                 |
|                             | W10575396       | White                       |
|                             | W10162245       | Black                       |
| 4                           | 3400029         | Nut                         |
| 5                           | W10162385       | Gasket, Door                |
| 6                           | W10544952       | Element, Broil              |
| 7                           | W10774342       | Element, Bake               |
| 8                           | W10362924       | Screw                       |
| 9                           | W10613792       | Assembly, Flue              |
| 10                          | W10289168       | Box, Burner                 |
| 11                          | W10341186       | Assembly, Front Foot        |
| 12                          | W10067840       | Screw                       |
| 13                          | W10541959       | Shield, Bake                |
| 14                          | W10137382       | Clip, Panel                 |
| 15                          | W10390008       | Assembly, Base Rail (Left)  |
|                             | W10390007       | Assembly, Base Rail (Right) |
| 16                          | W10058460       | Foot, Leveling              |
| 17                          | 3196548         | Fuse, Thermal               |
| 18                          | 3196172         | Screw                       |
| 19                          | W10035900       | Support, Oven Bottom        |
| 20                          | 3186034         | Bracket, Service            |
| 21                          | W10245259       | Block, Terminal             |
| 22                          | W10289166       | Back, Main                  |
| 23                          | 3196178         | Screw                       |

| <u>Illus.</u><br><u>No.</u> | <u>Part No.</u> | <u>Description</u>           |
|-----------------------------|-----------------|------------------------------|
| 24                          | W10454648       | Assembly, Light              |
| 25                          | 311255          | Bulb, Oven Light             |
| 26                          | 3400016         | Screw                        |
| 27                          | W10586204       | Sensor                       |
| 28                          | 3196169         | Screw                        |
| 29                          | W10655441       | Shield, Power Cord           |
| 30                          | W10031780       | Screw                        |
| 31                          | W10273192       | Rod, Door Switch             |
| 32                          | 9758701         | Spacer, Door                 |
| 33                          | W10774446       | Bottom, Oven                 |
| 34                          | W10627802       | Switch, Door                 |
| 35                          | W10281322       | Kit, Bare Wire Adapter Block |
| 36                          | W10655485       | Shield, Wire                 |
| 37                          | W10563084       | Assembly, Convection         |
| 38                          | W10346153       | Baffle, Full Convection      |
| 39                          | W10273002       | Bracket, Oven Support        |
| 40                          | W10346147       | Pan, Bake                    |
| 41                          | W10162255       | Duct, Cover                  |
| 42                          | W10162254       | Duct, Cooling                |
| 43                          | W10162259       | Assembly, Cooling Fan        |
| 44                          | W10162260       | Shield, Heat                 |
| 45                          | W10162241       | Channel, Rear                |
| 46                          | W10162248       | Cover, Wire                  |
| 47                          | W10289172       | Cover, Back                  |
| 48                          | W10603482       | Rack, Ladder                 |
| 49                          | W10554007       | Rack, Steam                  |

| <u>Illus.</u><br><u>No.</u> | <u>Part No.</u> | <u>Description</u>  |
|-----------------------------|-----------------|---|
| 50                          | W10554006       | Rack, Maximum Capacity  |
| 51                          | W10554008       | Rack, Sliding   |
| 52                          | W10686408       | Kit, Reservoir (Steam Rack)   |
| 53                          |                 | The wireless meat probe is a licensed product and covered by the manufacturer total replacement warranty. If the customer has any questions or concerns regarding the accessory please have them call KitchenAid Customer Satisfaction Center toll-free at 1-800-541-6390 or visit our web site at <a href="http://www.KitchenAid.com">www.KitchenAid.com</a> . No warranty claims will be paid for the wireless meat probe or will this be a service part. |
|                             |                 | INSULATION  |
|                             | W10655489       | Insulation, Wrapper   |
|                             | W10575374       | Insulation, Bottom  |
|                             | 4820F015-59     | Insulation, Strap   |
|                             | W10655490       | Insulation, Main Back   |
|                             | W10655442       | Insulation, Heat Shield   |
|                             | 7111P017-60     | Clamp, Wire   |

# DOOR PARTS




# DOOR PARTS

| <u>Illus.</u><br><u>No.</u> | <u>Part No.</u> | <u>Description</u>   |
|-----------------------------|-----------------|----------------------|
| 1                           | 9780274         | Screw                |
| 2                           |                 | Handle, Door         |
|                             | W10551000       | Stainless            |
| 3                           |                 | Badge                |
|                             | W10518672       | Grey                 |
| 4                           | W10541882       | Liner, Door          |
| 5                           | W10031790       | Screw                |
| 6                           | W10541888       | Glass, Inner         |
| 7                           | W10388635       | Hinge, Door (Active) |

| <u>Illus.</u><br><u>No.</u> | <u>Part No.</u> | <u>Description</u>             |
|-----------------------------|-----------------|--------------------------------|
| 8                           |                 | Panel, Door                    |
|                             | W10634273       | White                          |
|                             | W10634272       | Black                          |
|                             | W10634271       | Stainless                      |
| 9                           | W10541911       | Bracket, Glass Upper<br>Handle |
| 10                          | W10327235       | Screw                          |
| 11                          | W10541885       | Support, Glass                 |
| 12                          | W10031780       | Screw                          |

| <u>Illus.</u><br><u>No.</u> | <u>Part No.</u> | <u>Description</u>  |
|-----------------------------|-----------------|---------------------|
| 13                          | 8533988         | Screw               |
| 14                          | W10541883       | Hinge, Support Rail |
| 15                          |                 | Scoop, Door         |
|                             | W10613790       | White               |
|                             | W10613791       | Black               |
|                             | W10551024       | Stainless           |

# DRAWER PARTS





# DRAWER PARTS

| <u>Illus.</u><br><u>No.</u> | <u>Part No.</u> | <u>Description</u>    |
|-----------------------------|-----------------|-----------------------|
| 1                           |                 | Handle, Drawer        |
|                             | W10551000       | Stainless             |
| 2                           | W10634257       | Drawer, Bake          |
| 3                           | W10550987       | Seal, Drawer          |
| 4                           |                 | Panel, Drawer Front   |
|                             | W10541952       | White                 |
|                             | W10541953       | Black                 |
|                             | W10541954       | Stainless             |
| 5                           | W10541946       | Slide, Drawer (Left)  |
|                             | W10541945       | Slide, Drawer (Right) |

| <u>Illus.</u><br><u>No.</u> | <u>Part No.</u> | <u>Description</u>       |
|-----------------------------|-----------------|--------------------------|
| 6                           | W10327235       | Screw                    |
| 7                           | 3400882         | Screw                    |
| 8                           | W10634260       | Enclosure, Warming       |
| 9                           | W10727084       | Cover, Gas Valve         |
| 10                          | W10634259       | Cover, Wire              |
| 11                          | W10720530       | Sensor                   |
| 12                          | W10541944       | Element, Bake            |
| 13                          | W10551019       | Cover, Side              |
| 14                          | 3823F017-45     | Spacer, Handle           |
| 15                          | W10551018       | Insulation, Drawer Front |

| <u>Illus.</u><br><u>No.</u> | <u>Part No.</u> | <u>Description</u> |
|-----------------------------|-----------------|--------------------|
| 16                          | W10550982       | Insulation, Drawer |
| 17                          | W10541947       | Panel, Front Inner |
| 18                          | W10729897       | Fuse, Thermal      |
| 19                          | 3196560         | Screw              |
| 20                          | W10602493       | Rack, Bake Drawer  |

# OPTIONAL PARTS (NOT INCLUDED)

## PAINT, TOUCH-UP (1/2OZ.)

| <u>Illus.</u><br><u>No.</u> | <u>Part No.</u> | <u>Description</u>      |
|-----------------------------|-----------------|-------------------------|
|                             | 72017           | White                   |
|                             | 72032           | Black                   |
|                             | 4392899         | Biscuit/Bisque          |
|                             | 511873          | White Porcelain (2 oz.) |

## PAINT, PRESSURIZED SPRAY (12 OZ.)

| <u>Illus.</u><br><u>No.</u> | <u>Part No.</u> | <u>Description</u> |
|-----------------------------|-----------------|--------------------|
|                             | 350930          | White              |
|                             | 285006          | Black              |
|                             | 4392901         | Biscuit/Bisque     |

## PAINT, BULK (1 QT.)

| <u>Illus.</u><br><u>No.</u> | <u>Part No.</u> | <u>Description</u> |
|-----------------------------|-----------------|--------------------|
|                             | 799344          | White (Uncut)      |

## REFINISHING MATERIAL

| <u>Illus.</u><br><u>No.</u> | <u>Part No.</u> | <u>Description</u>           |
|-----------------------------|-----------------|------------------------------|
|                             | 242756          | Oven Liner Touch Up<br>Paint |

## INSULATION

| <u>Illus.</u><br><u>No.</u> | <u>Part No.</u> | <u>Description</u>                  |
|-----------------------------|-----------------|-------------------------------------|
|                             | 261514          | Insulation (1-1/2" x 24"<br>x 120") |
|                             | 240132          | Insulation (2-1/2" x 22"<br>x 120") |

## ACCESSORY PARTS

| <u>Illus.</u><br><u>No.</u> | <u>Part No.</u> | <u>Description</u>                 |
|-----------------------------|-----------------|------------------------------------|
|                             |                 | CLEANERS /<br>POLISHES             |
|                             | 31605           | Kit, Cooktop Care                  |
|                             | 31463A          | Protectant, Cooktop                |
|                             | W10355051       | Cleaner, Cooktop                   |
|                             | W10355016       | Cleaner, Stainless Steel           |
|                             | WA906B          | Scraper, Cooktop                   |
|                             | W10355049       | Wipes, Stainless Steel<br>Cleaning |
|                             | W10355010       | Cleaner, Kitchen &<br>Appliance    |
|                             | W10275756       | Cleaner, Granite                   |
|                             | 31617A          | Cleaner, Grate & Drip<br>Pan       |
|                             | W10432019       | Alt Cleaning Kit                   |
|                             | W10391473       | Pad, Cooktop Cleaning              |
|                             |                 | MISCELLANEOUS                      |
|                             | 4396923         | Broiler Pan and Grid               |
|                             | W10123240       | Rack, Broiler Pan &<br>Roasting    |
|                             | W10432539       | Griddle                            |
|                             | W10432545       | Kit, Grill                         |
|                             | 242905          | Kit, Canning Unit                  |
|                             |                 | TRIM KITS                          |
|                             | W10675026       | Black                              |
|                             | W10675027       | White                              |
|                             | W10675028       | Stainless                          |
|                             |                 | BACKSPLASH<br>ASSEMBLY             |
|                             | W10655449       | Black                              |
|                             | W10655448       | White                              |
|                             | W10655450       | Stainless                          |