

■ Order by Part Number


There is more than 1 version of this model. Page down to identify the version you have.

Illustrated Parts

Single-Handle Lever Style Kitchen Faucet

MODEL TYPE FINISH S798 Kitchen w/o spray Chrome

DISCONTINUED SKUS
8797 Kitchen w/spray Chrome





Handle Stop 12522

12523

Screws (2) & Red & Blue indicators

■ Order by Part Number

93400

Handle Screw 12536

Wrist Blade Handle Kit **14834** (Hot) 14838 (Cold)

Cartridge Nut (2)

Replacement Cartridge

or 96778 (Single Pack) (Also included in Spout Assembly)

Escutcheon Nut 12539

97535


Spout O-Ring Kit 117 (12 Pack)

Hardware Package

13805

1224

Illustrated Parts



TO ORDER PARTS CALL: 1-800-BUY-MOEN www.moen.com