

NOTE: If possible, change the trip lever before installing the toilet.

Disconnect the flapper ball chain from the existing trip arm. Remove the locknut by turning it clockwise. Remove the existing trip lever assembly from the tank.

Insert the trip arm of the replacement trip lever into the toilet tank hole. Secure the trip lever assembly with the washer (if supplied) and locknut. Remember that the locknut has left-hand threads. Do not overtighten the locknut, or the trip lever will not move freely. If the assembly binds, loosen the locknut slightly until free movement is achieved.

Hook the flapper ball chain to the hole in the trip arm. Check for proper chain length, and adjust as needed. Trip arm movement should be free of interference. The trip lever should be horizontal when at rest.

