


ASSEMBLY AND INSTALLATION INSTRUCTIONS

CC25653 / CC25655

WARNING: TO AVOID RISK OF **ELECTRICAL** SHOCK, BE SURE TO SHUT OFF POWER WHILE INSTALLING OR SERVICING THIS FIXTURE.

NOTE: Before installing, consult local electrical codes for wiring and grounding requirements.



Installation Steps:

1. Attach two screws to the mounting strap, and secure with two lock nuts.
(You can adjust the length of the screws if necessary.)
2. Attach the mounting strap to the ceiling box by using two mounting screws.
3. Make wire connections with wire nuts:
 - Connect the black wire from fixture to the black wire from power source.
 - Connect the white wire from fixture to the white wire from power source.
 - Attach the fixture grounding wire to the mounting strap with the green grounding screw. Then connect it to the house grounding wire with a wire nut.**Carefully tuck wires back into the **ceiling box**.
4. Attach the canopy to the ceiling box by inserting two screws, and secure with two bolt nuts.
5. Install bulbs. **(Please do not exceed the maximum capacity that is recommended on the package.)**
6. Thread the nipple into the coupling, and secure with a washer and a hex nut.
7. Attach the glass shade upward to the pan, and secure with the finial.
8. Turn on the power at fuse or circuit box.