

ASSEMBLY AND INSTALLATION INSTRUCTIONS

CH65306

WARNING: TO AVOID RISK OF ELECTRICAL SHOCK, BE SURE TO SHUT OFF POWER WHILE INSTALLING OR SERVICING THIS FIXTURE.

NOTE: Before installing, consult local electrical codes for wiring and grounding requirements.

Installation Steps

1. Attach the nipple-1 to the mounting strap, and then secure with a washer and a hex nut.
2. Attach the mounting strap to the ceiling box by using two mounting screws.
3. Adjust the arms of the fixture according to the drawing of the package.

Important to know:

a. The distance between the arms should be equally distanced.

b. The arms should be fixed securely.

4. Secure the loop to the nipple-2 of the fixture.
5. Choose the certain length of the chain that you need, and then weave the fixture wire and the grounding wire through the chain links. Connect one end link of the chain and the loop by using the loop lock.
6. Secure the top loop to the nipple.
7. Thread the fixture wire and grounding wire through the collar, canopy, top loop, nipple-1 and mounting strap in order.
8. Connect the link on the other end of the chains and the top loop by using the loop lock.
9. Make wire connections with wire nuts:
 - The smooth wire (marked) from fixture to the black wire from power source.
 - The ridged wire (unmarked) from fixture to the white wire from power source.
 - Attach the grounding wire to the mounting strap with the green grounding screw. Then connect it to the house grounding wire with the wire nut.Carefully tuck wires back into the ceiling box.
10. Attach the canopy to the mounting strap by inserting the top loop, and secure with the collar.
11. Attach the glass shades to the lamp holders, and secure with the socket rings.

Note: The glass shades should be all in horizontal line.
12. Install bulbs. **(Please do not exceed the maximum capacity that is recommended on the package.)**
13. Turn on the power at fuse or circuit box.

