INSTRUCTIONS: Model:


Builder Series Line Voltage Bar Lights BA-BX-1, BA-BX-2, BA-BX-3, BA-BX-4

CAUTION:

- Read all instructions before installing.
- Always turn off power at fuse box prior to installation to prevent electrical shock.
- For display wall or under cabinet only. Not intended for ceiling use.
- For installation by a qualified electrician.
- System is intended for installation in accordance with National Electric Code, and local regulations. Consult with local inspector to assure compliance.
- Keep away from combustible materials such as plastic or paper products.
- Do not touch cover when light is on. Do not operate with missing or damaged lens.
- All wires must be contained.

Wiring and Installation:

- 1. Remove the thumbscrews and glass lens.
- 2. The rear cover and reflector are one-piece. To remove: Press firmly on the rear cover down and back to release from the sheet metal tab (see diagram below). Then pivot the assembly up to expose wiring compartment.
- 3. Open a convenient knock out hole in the body of the fixture, and install the non-metallic sheathed cable connector supplied with the fixture. Allow approx 1 ½" of wire to enter the fixture body.
- Connect fixture wires with corresponding color supply wires (ground wire may be green or bare wire). Trim ¼" of insulation from the building wires and connect by pushing into one of the available holes in the connector.
- 5. Tuck wires connections neatly in the wiring compartment.
- 6. Replace the rear cover/reflector assembly.
- 7. Mount the fixture to the surface using the template and screws provided, then replace lens.



Wiring of multiple units:

In addition to hard wiring, components are provided to allow fixtures to be joined through surface wiring. **Note:** The total wattage of all connected fixtures should not exceed 700 watts.

End to End Connection (I-connector included):

The "I" connector allows two fixtures to butted end to end.

- 1. Pry out the plastic covers concealing the female connection ports at the end of the fixtures.
- 2. The "I" connector will only fit in the correct orientation.
- 3. Insert one end of the "I" connector into the fixture. Slide the next fixture to abut the original.
- 4. Secure position by mounting fixtures to the surface.

Interconnecting Fixtures with Jumper Wire (Sold Separately):

A surface mount jumper wire allows multiple units to be linked through surface wiring (see diagram below).


- 1. Pry out the plastic covers concealing the female connection ports at the end of the fixtures.
- 2. Jumper wire ends will only fit in the correct orientation.
- 3. Insert the ends of the connectors into each fixture.
- 4. Jumper wires use metal strain relief cover brackets. Slide the cover bracket over the connector. Position bracket and fixture holes and secure with screw provided.
- 5. Wrap excess wire with nylon wire ties.

Cord and Plug Use (Sold Separately):

Install the connector end of plug in line cord as described above (using a Jumper wire).

TO RE-LAMP

- Turn off fixture and allow it to cool before replacing lamp.
- For use with Xenon (not tungsten halogen) G8 bi-pin 120 Volt 25 Watt lamps.
 - 1. Remove the lens to expose the lamps.
 - 2. Withdraw the lamp by pulling away from the ceramic socket base.
 - 3. Re-lamping is the reverse procedure.



Re-lamping



Retain these instructions for future service and adjustments 615 South Street, Garden City, NY 11530 Tel: (516) 515-5000 Fax (516) 515-5050 www.waclighting.com