




COMPACT ELECTRIC DRYER

MODELS:

NEC3120FW0 (White)


TOP AND CONSOLE PARTS



TOP AND CONSOLE PARTS

<u>Illus.</u> <u>No.</u>	<u>Part No.</u>	<u>Description</u>	<u>Illus.</u> <u>No.</u>	<u>Part No.</u>	<u>Description</u>	<u>Illus.</u> <u>No.</u>	<u>Part No.</u>	<u>Description</u>
1		Literature Parts	6	348171	Bracket, Timer	11	W10503561	Switch, Push-To-Start
	W10773366	Use & Care Guide	7	3400882	Screw	12		Knob, Push To Start
	W10828140	Energy Guide	8		Top		8544939	White
2	3406860	Bracket, Front Panel		345703	White	13	339554	Screw
3	307563	Rivet, Pop	9	W10772591	Panel, Control	14	8536939	Clip, Spring
4	8563881	Timer, 60 Hz.	10		Assembly, Timer Knob			
5		(Timer Motor Not Serviceable)		8544955	White			


CABINET PARTS



CABINET PARTS

<u>Illus.</u> <u>No.</u>	<u>Part No.</u>	<u>Description</u>	<u>Illus.</u> <u>No.</u>	<u>Part No.</u>	<u>Description</u>	<u>Illus.</u> <u>No.</u>	<u>Part No.</u>	<u>Description</u>
1	343641	Screw	16		Panel, Side	29	695656	Door, Rear
2	347812	Panel, Rear		348705	White	30		Door, Front
3	348726	Base Assembly	17	W10239317	Cord, Power		348205	White
4	660658	Clamp, Motor	18	3406104	Door Switch Assembly	31	8562104	Handle, Door
5	W10396037	Motor, Main Drive (60 Hz)	19	697773	Screw	32	660719	Caster
6	8533971	Screw	20		Panel, Front	33	3393657	Restrainer, Belt
7	696541	Base, Motor		8066229	White			
8	8066084	Bushing, Snap	21	685203	Clip, Felt Pad			
9	691366	Idler Assembly	22	8066123	Seal and Bearing Assembly			
10	3390631	Screw	23	345670	Lock Top			
11	98234	Clip, Ground	24	3389441	Assembly, Door Catch			
12	8066051	Pulley, Motor	25	348023	Hinge and Pin Assembly			
13	345790	Bracket, Power Cord	26	696144	Strike, Door			
14	W10775448	Clip, Front Panel	27	W10823581	Seal, Door			
15	8066064	Belt, Drive	28	342055	Screw			

BULKHEAD PARTS



BULKHEAD PARTS

<u>Illus.</u> <u>No.</u>	<u>Part No.</u>	<u>Description</u>	<u>Illus.</u> <u>No.</u>	<u>Part No.</u>	<u>Description</u>	<u>Illus.</u> <u>No.</u>	<u>Part No.</u>	<u>Description</u>
1	W10389567	Shield, Exhaust	17	3404153	Thermostat (180~F)	31	685207	Baffle, Drum
2	696545	Air Duct Assembly	18	348197	Washer	32	3394508	Ring, Bearing
3	8533971	Screw	19	90767	Screw	33	342202	Screw, Tapping
4	660074	Thermostat (145~F)	20	W10476828	Control, Electronic	34	W10512946	Washer, Tri Ring
5	345965	Guard, Exhaust	21	3391885	Terminal	35	3397590	Roller, Support
6	339956	Seal	22	3403591	Element, Heater	36	W10359270	Shaft, Drum Roller - Left Hand Thread
7	696426	Wheel, Blower	23	279457	Terminal Wire Kit (For Heater Element Wiring Harness Repair)	37	W10359269	Shaft, Drum Roller - Right Hand Thread
8	W10503559	Buzzer, Mini	24	3976479	Pad, Sensor	38	8066086	Plug, Drum Hole
9	489463	Screw	25		Screen, Back-up (Not Serviceable)	39	8066094	Seal, Fan Scroll
10	696419	Scroll, Fan	26	345325	Gusset	40	3388703	Washer
11	3394204	Bulkhead	27	W10298789	Nut, Hex	41	8531964	Lint Screen
12	3398161	Clip, Heater Box	28	695943	Drum Assembly Complete	42	W10488664	Harness, Wiring
13	3401380	Box, Heater	29	345648	Seal, Drum Rear	43	8531966	Cover, Lint Screen Outlet
14	343641	Screw	30	W10219342	Screw			
15	359702	Cap						
16	9830393	Clip						

OPTIONAL PARTS (NOT INCLUDED)

PAINT, TOUCH-UP (1/2OZ.)

<u>Illus.</u> <u>No.</u>	<u>Part No.</u>	<u>Description</u>
	72017	White

PAINT, PRESSURIZED SPRAY (12 OZ.)

<u>Illus.</u> <u>No.</u>	<u>Part No.</u>	<u>Description</u>
	350938	Gray Primer
	350930	White

PAINT, BULK (1 QT.)

<u>Illus.</u> <u>No.</u>	<u>Part No.</u>	<u>Description</u>
	799344	White (Uncut)