



HOOKER
— FURNITURE —





ASSEMBLY INSTRUCTION

Item: 5453-55484-MWD-Entertainment Console

Thank you for purchasing this quality product. Be sure to unpack carefully looking for small parts which may have come loose during shipment.

Read all instruction and study the drawing carefully before starting the assembly process:

HARDWARE PACK

NO	DRAWING	DESCRIPTION	SIZE	QTY
A		BOLT	Φ5/16"*2-1/2"	6pcs
B		FLAT WASHER	Φ5/16"*19*2	6pcs
C		LOCK WASHER	Φ5/16"*12*3	6pcs
D		ALLEN WRENCH	5mm	1pc

