


INSTALLATION INSTRUCTIONS

V/A

V/A CHANDELIER DOWN

- ART. NO. 300 222ch/dn chrome, 22" diameter, 75W max, with 3 fixtures
 300 222mc/dn matte chrome, 22" diameter, 75W max, with 3 fixtures
 300 230ch/dn chrome, 30" diameter, 150W max, with 6 fixtures
 300 230mc/dn matte chrome, 30" diameter, 150W max, with 6 fixtures



IMPORTANT SAFETY INSTRUCTIONS



1. Read all instructions!
2. Turn off power prior to any work on the canopy.
3. Do not install this track in a damp or wet location.
4. Never connect the system and lamps directly to the main power source without the use of a transformer. This system must be used in conjunction with low voltage, 12V transformer.
5. Total wattage of the system must not exceed 75 - 150W supplied by the low voltage transformers.
6. Suspension cables are conductive and should not touch other parts of the track or crossed.
7. CAUTION! Lamps and fixtures become hot during operation.
8. Observe the stated minimum distance of the illuminants to flammable objects.
9. Do not hang any objects over the system; short circuit and fire hazard.
10. Warranty is void in case of unauthorized modifications and/ or improper use.

READ ALL OF THESE INSTALLATION INSTRUCTIONS BEFORE INSTALLING THE SYSTEM

- The VIA Chandelier can be mounted directly onto any standard junction box with access to the power cables.

- Begin by connecting the two wires from the transformer (A) to the power cables in the wall then slide the notched plastic washer (B) through the mounting screws (C).

- Insert the screw (C) into the mounting plate (D) and slide the plastic washer (E) onto the end of the screw. Align the screws (C) with the J-box and tighten until firmly connected.

- Place the canopy cover (F) over the mounting plate (D) and secure it with the allen screw (G) located on the side of the base.

- Insert a Bi-Pin lamp (H) into the socket (I) and screw on desired glass.

- The chandelier can be shortened to the desired length by loosening the two allen screws (J) located to the side of the power feed.

- Once the desired length is reached, tighten the allen screws (J) and trim off any excess cables from below.

