

Franklin Electric Co., Inc. P. O. Box 12010 Oklahoma City, OK 73157-2010 405.947.2511 • Fax: 405.947.8720 www.LittleGiantPump.com CustomerService-WTS@fele.com

# COTTAGE CAULDRON MODEL FP-CC-V

# INTRODUCTION

This instruction sheet provides you with the information required to safely own and operate your product. Retain these instructions for future reference.

The product you have purchased is of the highest quality work-manship and material, and has been engineered to give you long and reliable service. This product has been carefully tested, inspected, and packaged to ensure safe delivery and operation. Please examine your item(s) carefully to ensure that no damage occurred during shipment. If damage has occurred, please contact the place of purchase. They will assist you in replacement or repair, if required.

READ THESE INSTRUCTIONS CAREFULLY BEFORE ATTEMPTING TO INSTALL, OPERATE, OR SERVICE YOUR PRODUCT. KNOW THE PRODUCT'S APPLICATION, LIMITATIONS, AND POTENTIAL HAZARDS. PROTECT YOURSELF AND OTHERS BY OBSERVING ALL SAFETY INFORMATION. FAILURE TO COMPLY WITH THESE INSTRUCTIONS COULD RESULT IN PERSONAL INJURY AND/OR PROPERTY DAMAGE!

# **SAFETY GUIDELINES**



Disconnect the pump from power before servicing or removing any component.

Do not use to pump flammable or explosive fluids such as gasoline, fuel oil, kerosene, etc. Do not use in explosive atmospheres. Pump should only be used with liquids compatible with pump component materials.

Do not handle pump with wet hands or when standing on a wet or damp surface or in water.

This pump is supplied with a grounding conductor and/or grounding type attachment plug. To reduce the risk of electric shock be certain that it is connected to a properly grounded grounding type receptacle.

The National Electric Code (in the USA) and similar codes in other countries require a Ground Fault Circuit Interrupter (GFCI) to be installed in the branch circuit supplying fountain equipment rated above 15 volts. Little Giant recommends that each pump be used with a GFCI.

Do not allow children or infants to play near the fountain due to drowning hazard.

# **ELECTRICAL CONNECTIONS**



- 1. Check the pump label for proper voltage required. Do not connect to voltage other than that shown.
- 2. If pump is supplied with a 3-prong electrical plug, the third prong is to ground the pump to prevent possible electrical shock hazard. DO NOT REMOVE the third prong from the plug. A separate branch circuit is recommended. Do not use an extension cord. Do not cut plug from the cord. Cutting the plug or shortening the cord will void the warranty.

#### **ASSEMBLY AND OPERATION**

- Remove the fountain assembly and all packaging from the box and place them on a smooth, flat surface. NOTE: The suction cups and adapter are not required for this application and are not included.
- 2. Remove the ornamental pump from the cauldron.
- 3. Locate flexible tubing on the ornamental pump and connect the tubing to the electric pump.
- 4. Feed the electrical plug through the center hole at the top of the cauldron and then through the overfill hole at the base of the cauldron, allowing the electrical pump to go through the center hole but sit at the bottom of the cauldron.
- 5. Fill the cauldron with water until the electric pump is fully submerged.
- 6. Align the ornamental pump on the cauldron and loosen the mounting bolts so that the ornamental pump can stand flat on the top surface.
- 7. Tighten the mounting bolts into the mounting holes using a wrench. DO NOT OVER-TIGHTEN.
- 8. Connect the electric pump to power and allow approximately 20 seconds for water to begin flowing from the ornamental pump.
- 9. Use the adjustment on the pump to regulate the flow of water.

#### **MAINTENANCE**

- 1. Do not allow the pump to run without water or to freeze.
- Clean fountain only with water and, if desired, use only a tablespoon of chlorine to prevent algae. DO NOT USE BLEACH. It may tarnish the applied finish.

## **TROUBLESHOOTING**

PROBLEM	CORRECTIVE ACTION
Pump is not working.	Check power outlet. Refer to manufacturer's instructions.
Pump is working but water is not flowing.	Check for kinks in the tube. Make sure pump is submerged. Make sure pump is free of debris and the impeller turns freely by cleaning the inside of the pump.

## **WARRANTY**

One year limited warranty from date of purchase. Contact the manufacturer for all warranty details.

> www.LittleGiantPump.com CustomerService-WTS@fele.com